



Spindle		14	0			1	1
---------	--	----	---	--	--	---	---

FWD either jumped to DCM (gnd) or wired to an output on MX3660
 10V from VFD to +10Vdc on MX3660
 ACM(common) from VFD to EGND on MX3660
 VI to 0-10V on MX3660

VFD Parameter set
 PD001 needs to be changed to = 1 (for external control)

